



Kyros


quick programming
guide



Program your Kyros products
the quickest way.




Learn how to optimise your consumption without affecting comfort



Set correct temperature

The average comfortable temperature is 21°C. So, we recommend a temperature between **18 - 21°C** to keep your home warm, whilst helping reduce energy consumption.


Reducing the temperature by just 1°C, can **save you up to £75 per year.***



Do not cover product

Our products transfer heat through **natural air convection**. If the product is covered, this will interrupt air flow and could cause an overheating or fire risk.

Please **do not** cover the products or place any object (including furniture) directly in front of them.





Program correctly

We recommend **3-4 hour heating periods under 21°C, three times a day**. In between, the product should be set to off or eco mode. Your radiators will be on for 9-12 hours a day at a constant, comfortable heat.

Program your product to switch on 1 hour before using the room, for a warm space without excessive consumption.



KYROS CONTROL PANEL



1	Current programming set
2	Days of the week
3	Current time
4	Current temperature set
5	Control panel locked / unlocked
6	Manual / automatic mode active
7	Comfort / eco / anti-frost mode active
8	Fuzzy Logic technology / heating element active
9	Consumption indicator
10	Open Windows indicator

KYROS



KYROS BASIC OPERATION

















Turn product on / off

- Press  once.

Lock / unlock control panel

- Press and hold  and  together for 3 seconds.

Adjust day and time



- Press  once.
- Use  and  to highlight  for settings and press .
- Highlight  for day/time and press .
- Use  and  to set hour and press .
- Use  and  to set minutes and press .
- Use  and  to set day (1 for Monday, 2 for Tuesday etc.) and press .

Switch between manual & automatic mode

- An **M** (manual) or **A** (automatic) will appear on the main screen to show which mode is active.
- Use **MAN/AUTO** to toggle between MAN (manual) or AUTO (automatic).





Turn Open Windows function on / off

- Press **MENU** once.
- Use **-** and **+** to highlight  for energy saving functions and then press **POWER**.
- Highlight  for Open Windows and press **POWER**.
- Use **MENU** and **MAN/AUTO** to select ON or OFF, press **POWER** to confirm and exit to main screen.





Adjust screen brightness

- Press **MENU** once. Use **-** and **+** to highlight  for settings and then press **POWER**.
- Highlight  for brightness and press **POWER**.
- Use **MENU** and **MAN/AUTO** to choose backlight or standby screen.
- Use **-** and **+** to adjust the level of brightness.
- Press **POWER** to confirm and exit to main screen.



Check consumption status

- Press **MENU** once. Use **-** and **+** to highlight  for settings and then press **POWER**.
- Highlight  for Consumption status and press **POWER**.
- The display will show status according to current consumption.



Manually adjust temperature.
Switch radiator on/off when required.
No automatic programming.

KYROS MANUAL MODE

1. Select Manual mode

- If **[A]** (automatic) shows on the main screen, follow steps below. If **[M]** (manual) shows then manual mode is active so skip to step 2.
- Use **MAN/AUTO** to toggle between MAN (manual) or AUTO (automatic). An **[M]** will appear on the main screen.

2. Select temperature

- Press **⊖** to decrease temperature.
- Press **⊕** to increase temperature.

3. Switch radiator off when heating not required

- Press **⏻** once.
- Press **⏻** again to switch radiator back on when heating required.
- The previous temperature and programming set will activate.



Schedule automatic programming for each day & hour of week using comfort & eco modes. Or choose pre-installed programs.

KYROS AUTOMATIC MODE

1. Select Automatic mode

- If **M** (manual) shows on the main screen, follow steps below.
- If **A** (automatic) shows then automatic mode is active so skip to step 2.
- Use **MAN/AUTO** to toggle between MAN (manual) or AUTO (automatic).
- An **A** will appear on the main screen.



2. Go to programming menu

- Press **MENU** once.
- Use **-** and **+** to highlight **7** for programming and press **⏻**.
- Display will show two options: PREPROGRAMS or START PROGRAMMING.
- To select a pre-installed program go to step 3.
- To program your own heating schedule, go to step 4.



3. Select pre-installed program

- Use **-** and **+** to highlight PREPROGRAMS and press **⏻**.
- Use **-** and **+** to highlight the pre-installed program you wish to activate (A1, A2, A3 or A4) and press **⏻**.
- You can find the pre-installed program schedules overleaf.



4. Program own heating schedule.

- Use **-** and **+** to highlight START PROGRAMMING and press **⏻**.

5. Select comfort mode temperature

- Use **-** and **+** to set comfort mode temperature between 19 - 30°C.
- Press **⏻**.







6. Select eco mode temperature

- Use **-** and **+** to set eco mode temperature between 7.5 - 18.5°C.
- Press **⏻**.







KYROS

7. Select days

- Start on day 1 (Monday). Press  to include this day in programming. The day will stop flashing. If you press  again the day will be excluded and start flashing.
- Use  to move forwards a day.
- Repeat for all days of the week.
- Press  to move to next part of programming.



8. Select hours

- Start on 0h (midnight). Press  to choose eco, press  again for comfort or press  again for off mode for this hour.
- Use  to move onto the next hour 1h (1am) and repeat the eco / comfort / off mode selection using .
- Repeat until all hours of the day are programmed.
- Press to  confirm and exit.



NOTE

- If you need different programming on individual days then repeat steps 2 to 8 above for each day.



Pre-installed program schedule:

PROGRAM	A1		A2		A3	A4	
	Mon - Fri	Sat - Sun	Mon - Fri	Sat - Sun	Mon - Sun	Mon - Fri	Sat - Sun
00:00					ECO		
01:00					ECO		
02:00					ECO		
03:00					ECO		
04:00					ECO		
05:00					ECO		
06:00	COMFORT		COMFORT		COMFORT		
07:00	COMFORT	COMFORT	COMFORT	COMFORT	COMFORT	COMFORT	ECO
08:00	COMFORT	COMFORT	COMFORT	COMFORT	COMFORT	COMFORT	ECO
09:00	COMFORT	COMFORT	COMFORT	COMFORT	COMFORT	COMFORT	ECO
10:00	ECO	COMFORT	ECO	COMFORT	COMFORT	COMFORT	ECO
11:00	ECO	ECO	ECO	ECO	COMFORT	COMFORT	ECO
12:00	ECO	COMFORT	COMFORT	COMFORT	COMFORT	COMFORT	ECO
13:00	ECO	COMFORT	COMFORT	COMFORT	COMFORT	COMFORT	ECO
14:00	ECO	COMFORT	COMFORT	COMFORT	COMFORT	COMFORT	ECO
15:00	COMFORT	COMFORT	ECO	COMFORT	COMFORT	COMFORT	ECO
16:00	COMFORT	ECO	ECO	ECO	COMFORT	ECO	ECO
17:00	COMFORT	ECO	COMFORT	ECO	COMFORT	ECO	ECO
18:00	COMFORT	ECO	COMFORT	ECO	COMFORT	ECO	ECO
19:00	COMFORT		COMFORT	COMFORT	COMFORT	ECO	ECO
20:00	COMFORT		COMFORT	COMFORT	COMFORT	ECO	ECO
21:00	COMFORT		COMFORT	COMFORT	COMFORT	ECO	ECO
22:00	COMFORT		COMFORT	COMFORT	COMFORT	ECO	ECO
23:00	ECO				ECO		



COMFORT	
ECO	
OFF	

If you have any questions or need help, please contact us:

0203 321 5929 · support@rointe.co.uk

Mon to Fri from 7.30 am to 5.30 pm

Professional team, always happy to help



Rointe United Kingdom

Catalyst House, 720 Centennial Court, Centennial Park, Elstree, Herts, WD6 3SY | T. 0203 321 5928 | F. 0208 953 5861

Rointe Ireland

Blackrock, County Louth | T. 01 553 0523 | F. 01 553 0524

Rointe España

P.I. Vicente Antolinos - C/ E, p. 43, 30140 Murcia | T. 902 158 049 | F. 968 277 125

Rointe France

6 Rue Duret, 75116 Paris | T. 01 73 05 70 01

Rointe Россия

121069, Поварская 10/1, 4 этаж, Москва | T. 917 541 70 69